





## 9000 Series DOOR FURNITURE


## **Limiting Dimensions**






















































The above catalogue numbers are for Passage Knobsets. For Dummy Knob version, add 'D' to the number shown, followed by the finish code.