







	<p>1. MARK DOOR Start approximately 915mm from floor. Fold and apply template on high edge of door bevel and mark center point on door edge for latch hole and door face for side hole. (follow template instructions)</p> <p>NOTE: Check box label for either a 60mm or 70mm backset</p>	<p>NOTE: For entry locksets, guard bolt must stop against strike as illustrated, preventing forcing when door is closed.</p>
	<p>2. BORE TWO HOLES</p> <p>A. Bore a 54mm hole through door face for lockset. (It is recommended to bore hole from both sides of door to avoid splintering.)</p> <p>B. Bore a 25.4mm hole, depending on latch housing diameter, straight into the center of door edge to intersect with center of 54mm hole.</p> <p>NOTE: For drive-in latch, bore a 24.6mm hole.</p>	
	<p>3. INSTALL LATCH</p> <p>A. Insert latch in edge, keeping its face parallel to face of door. Mark outline of latch face and remove latch.</p> <p>B. Chisel 3mm deep or until latch face is flush with door edge.</p> <p>C. Insert latch and secure with two wood screws. <u>Tighten screws.</u></p> <p>D. For drive-in latch, press latch bolt until surface of collar is flush with door edge.</p> <p>NOTE: Latchbolt bevel must face to closing direction.</p>	
	<p>4. INSTALL STRIKE</p> <p>A. (1) Close door until latch bolt touches door jamb. Mark horizontal center line along latch face.</p> <p>(2) Measure one half of door thickness from one half of door jamb and mark vertical center line.</p> <p>(3) Extend horizontal center line and vertical center line. Then mark center point for strike.</p> <p>B. Bore a 25.4mm hole, 15mm deep in door frame at center point.</p> <p>C. Chisel door jamb 1.6mm deep or until strike is flush with door frame. Install strike and tighten with two wood screws.</p>	 <p>Backset is the distance from door edge to center of hole on door face. Some locksets are supplied with adjustable latch which can fit either 60mm or 70mm backset. Just follow the steps shown below to change backset.</p>
<p>TEMPLATE</p> <p>① Fold along dotted line and fit on door edge</p> <p>② Mark proper door thickness</p> <p>④ Bore 25.4mm or 24.6mm hole in center of door edge</p> <p>⑤ Bore 54mm hole</p> <p>③ Mark either 60mm or 70mm backset</p> <p>Place template on high edge of door bevel</p> <p>70mm backset</p> <p>60mm backset</p> <p>45mm 40mm 35mm 32mm</p>	 <p>A. Latch is factory set for a 60mm backset.</p> <p>B. Keep hub in correct position as illustrated. Adjust by grasping the hub between thumb and forefinger and slide to right side.</p> <p>C. Latch is now set for 70mm backset. To re-adjust latch to 60mm backset, just push slide extension back to left side.</p>	 <p>Some locksets are supplied with 4-way latch which can fit either mortise-in or drive-in.</p> <p>A. This latch is for mortise-in.</p> <p>B. Rotate latch face clockwise 20 degree and pull out latch face.</p> <p>C. This latch is for drive-in.</p>